

# Temperature controller

1/16 DIN - 48 x 48

M3 line



Quick Guide • QG M3 - 1/11.09 • Cod. J30-478-1AM3 QG



## Declaration of conformity and manual retrieval

Class II instrument, rear panel mounting. This controller has been designed with compliance to the European Directives. Consult Declaration of Conformity for further details on Directives and Standards used for Compliance. Declaration of Conformity can be found in the file **ASCON\_DC\_G2.zip**.

All information about the controller usage are inserted in the user manual (**ASCON\_MIU\_M3\_EN.zip**).

The Declaration of Conformity and the manual of the controller can be downloaded (free of charge) from the web-site:

**www.ascontecnologic.com**

Once connected to the web-site, click on the **ascon** logo. Select: **Download/Documentation**, and fill the table with:

- Typology: **Manual**; Type: **All**; Language: **All**;
- Code: **GAMMA2**

Click: **SEARCH** and

- Download the file: **ASCON\_DC\_G2.zip** (Declaration of Conformity of gamma2 controllers)
- ASCON\_MIU\_M3\_EN.zip** (M3 manual)

### Warning!

- Whenever a failure or a malfunction of the device may cause dangerous situations for persons, things or animals, please remember that the plant must be equipped with additional devices which will guarantee safety.
- We warrant that the products will be free from defects in material and workmanship for 18 months from the date of delivery. Products and components that are subject to wear due to conditions of use, service life, and misuse are not covered by this warranty.

## Configuration Code

A 4 + 1 digits index code follows the model (letters from I... 0).

This code must be set to configure the controller.


Using UP (▲) and DOWN (▼) keys insert the desired configuration code. When not configured the 1<sup>st</sup> part of the code is 9999.

Input type and range	I	L	
TR Pt100 IEC751	-99.9...300.0°C	-99.9...572.0°F	0
TR Pt100 IEC751	-200...600°C	-328...1112°F	1
TC L Fe-Const DIN43710	0...600°C	32...1112°F	2
TC J Fe-Cu45% Ni IEC584	0...600°C	32...1112°F	3
TC T Cu-CuNi	-200...400°C	-328...752°F	4
TC K Chromel-Alumel IEC584	0...1200°C	32...2192°F	5
TC S Pt100%Rh-Pt IEC584	0...1600°C	32...2912°F	6
Dc input 0...50mV linear	Engineering and units		7
Dc input 10...50mV linear	Engineering and units		8
Custom input and range [1]			9


[1] For instance, other thermocouples types, ΔT (with 2 Pt100), custom linearisation etc..

## Description and dimensions


Depth: 120 mm




## Panel cut out and mounting



## Electrical connections



## Terminals



via Indipendenza 56, 27029 - Vigevano (PV)  
Tel.: +39 0381 698 71, Fax: +39 0381 698 730  
internet site: www.ascontecnologic.com  
E-mail: sales@ascontecnologic.com

## Model Code

The product code indicates the specific hardware configuration of the instrument, that can be modified by specialized engineers only.

Line	Basic	Accessories	Configuration 1 <sup>st</sup> part	Configuration 2 <sup>nd</sup> part
Model:	M3	ABCD	E900	ILMN-O

Line	M	3	
<b>Power supply</b>		<b>A</b>	
100...240Vac (-15...+10%)		3	
24Vac (-25...+12%) o 24Vdc (-15...+25%)		5	
<b>Outputs OP1 - OP3</b>		<b>B</b>	
Relay - Relay		1	
Relay - Triac		2	
<b>Serial Comm.s</b>		<b>C</b>	
		<b>D</b>	
Not fitted	None	0	0
	Current transformer input (CT)	0	3
	Transmitter Power Supply (P.S.)	0	6
	Transmitter P.S. + Retransmis.	0	7
	Transmitter P.S. + CT	0	8
Transmitter P.S. + Retransmis. + CT	0	9	
RS485 Modbus/Jbus SLAVE	None	5	0
	Transmitter Power Supply (P.S.)	5	6
	Transmitter P.S. + CT	5	8
<b>Special functions</b>		<b>E</b>	
Not fitted		0	
Start-up + Timer		2	


## Controller configuration chart

The present chart includes only the basic parameters

For the list and the description of all the controller parameters see the User Manual.

When the controller is new and not configured shows the code 9999 at power ON. In this case NO PASSWORD is needed to configure the instrument (see the grey box in the chart below). Enter the configuration code in accordance with the desired functional characteristics.

**Warning!** If the parameter **CodeP** has previously set to a value  $\geq 5000$ , (for example 5033 in the chart) the controller is locked in operator mode; insert the correct password to access both the parameter and the configuration menus.



**Automatic tuning**  
To determine the PID values for the process, run the **tuneP** procedure: press the **tuneP** key until the display shows: **tuneP**; press the **▲** **▼** keys to select **SetP**; then press **▶** to run the automatic tuning procedure (to end the tuning procedure press **▶** to select **SetOP** then **▶**). At the end the PID parameters are entered.

Table 1 Engineering Units

Value	Description
°C	degree Celsius
°F	degree Fahrenheit
none	none
mV	mV
V	Volt
mA	mA
A	Ampère
bar	Bar
PSI	PSI
Rh	Rh
pH	pH

Notes: [3] A not configured controller shows 9999 at power ON: the configuration procedure is shown in the grey box.  
[4] The controller shows P355 after conf: using the keys ▲ and ▼ insert the password to configure the controller.

## Parameter list

The parameters pointed out with grey background are those necessary to configure the options and are NOT shown in the configuration chart. All the parameters are fully described and explained in the user manual of the controller.

Code	Parameter Name	Value	
		Default	User
CONF	1 <sup>st</sup> Configuration code	9999	
CONF2	2 <sup>nd</sup> Configuration code	0000	
Unit	Engineering units	NONE	
Scdd	Decimal point	0	
ScLo	Low range for engineering units	0	
ScHi	High range for engineering units	9999	
ETmode	Timer/Start-up operating mode	OFF	
ETAct	Timer Action	OFF	
PrAct	Communications protocol	JBUS	
baud	Baud rate	9600	
rPRr	Continuous Output range	4...20	
rEFS	Retransmitted signal selection	PV	
HEFS	Current transformer range	OFF	
CodeP	Password	33	
ETrun	Timer run/stop	Stop	
A2SP	Al2 alarm threshold	0	
A3SP	Al3 alarm threshold	0	
Pb	Proportional band (Hysteresis ON - OFF)	5.0	
ti	Integral time	5.0	
td	Derivative time	1.00	
tc	Output Cycle time	20	
OCrb	Overshoot Control relative band	1.00	
cc	Cool cycle time	20	
rCG	Relative Cooling Gain	1.0	
hy	Cool output Hysteresis (ON-OFF only)	0.5	
dbnd	Heat/Cool Dead band	0.5	

Code	Parameter Name	Value	
		Default	User
OP.H	Control output high limit	100.0	
OP.HC	Cool output maximum value	100.0	
hy	Control output hysteresis (ON-OFF only)		
tuneP	Start/Stop One shot tuning (o=Stop=Run)	STOP	
ETPR	Timer Setting	1	
SP.2	Stand-by Setpoint	0	
SL.u	Slope up	OFF	
SL.d	Slope down	OFF	
SP.L	Setpoint low limit	PV.LO	
SP.H	Setpoint high limit	PV.HI	
SP.HL	Start-Up Setpoint	0	
EH.HL	Start-Up Hold time	1	
OP.HS	Output high limit during Start-up	100.0	
A2Hy	Al2 Alarm Hysteresis	0.5	
A2Lb	Al2 latching and blocking functions	NONE	
A3Hy	Al3 Alarm Hysteresis	0.5	
A3Lb	Al3 latching and blocking functions	NONE	
ELBR	Loop Break Alarm delay	OFF	
EFIL	Input filter	2.0	
InSh	Input shift	OFF	
dErr	Error Dead Band	OFF	
StOP	Soft start output value	OFF	
StEN	Soft-start activation time	1	
SaOP	Output safety value	0.0	
Addr	Serial comm address	1	
rELo	Retransmission low range	PV.LO	
rEH	Retransmission high range	PV.HI	

[2] This function can be set only when the CT option is installed.